

Setting the EH40 Water Heater Timer for Monday through Friday

To set Summer schedule:

Press reset using a pin, toothpick, paper clip, pencil tip or some other pointed item.

Go to Time Set and set day and time

Go to Program and if needed, press Event **until display reads “On”**

Press Day until display reads Mon Tues Weds Thurs Fri

Set first on at 8:05 p.m. and press Event

Press Day and set first off at 1:55 p.m. and press Event

To continue to program for the weekend:

Press Day to display Sat Sun and set second on at 12 a.m. and press Event

Press Day to display Sat Sun and set second off at 11:55 p.m. and press Event

Set switch to Run

To set Winter schedule:

Press reset

Go to Time Set and set day and time

Go to Program and if needed, press Event **until display reads “On”**

Press Day until display reads Mon Tues Weds Thurs Fri

Set first on at 9:05 a.m. and press Event

Press Day and set first off at 4:55 p.m. and press Event

Press Day and set second on at 9:05 p.m. and press Event

Press Day and set second off at 4:55 a.m. and press Event

To continue to program for the weekend for third on and third off:

See Summer Schedule above

Set switch to Run

(More on back)

To set Summer and Winter schedules together:

Press reset

Go to Time Set and set day and time

Go to Program and if needed, press Event until display reads "On"

Press Day so display reads Mon Tues Weds Thurs Fri

Set first on at 12 a.m. and press Event

Press Day and set first off at 4:55 a.m. and press Event

Press Day and set second on at 9:05 a.m. and press Event

Press Day and set second off at 1:55 p.m. and press Event

Press Day and set third on at 9:05 p.m. and press Event

Press Day and set third off at 11:55 p.m. and press Event

To continue to program for the weekend:

Press Day to display Sat Sun and set fourth on at 12 a.m. and press Event

Press Day to display Sat Sun and set fourth off at 11:55 p.m. and press Event

Set switch to Run

If, after programming, the display shows "Off" during a time when the water heater should be on, slide the switch to "Manual" and press "Day." "On" will show up on the display. Slide switch back to "Auto."

Note: The timer's clock does not automatically reset for daylight savings or standard times. Remember to adjust the clock's time prior to the time changes.